

# Convac 3000CQ Vacuum Cleaner



## Operating/Safety Instructions

Read all instructions before using this appliance

### General Information

Convac 3000CQ Vacuum Cleaners has patented air inlet valve system that prevents dust spills once the hose is disconnected from the cleaner.

Convac 3000CQ Vacuum Cleaner is intended for commercial use only.

To obtain the best performance of the vacuum cleaner the manufacturer's recommendation should be followed:

- 1 : Use only Convac Cartridge Filters obtainable from your supplier.
- 2 : Used, filled with toner cartridge filters dispose in compliance with local regulations
- 3 : Always replace the red hose end caps after use to prevent contamination.
- 4 : Before switching the Vacuum Cleaner off, stretch the hose to its full length in order to remove any remaining toner from the hose and its attachment.

Disconnect the hose and then, switch the cleaner OFF.

### Important

- 1 : Use only CONVAC spare parts—Full list of parts is available from your supplier.
- 2 : Removal of the motor cover or any unauthorised tampering with the cleaner or use without a full filtration system invalidates any warranty that may be given
- 3 : This appliance should only be connected to a grounded power socket. Static charge may build up on the utensils and the cleaner body when picking up a fine dust like, for instance, toner. Grounding provides an electrical path for that charge to dissipate safely to the ground.
- 4 : All attachments, crevice tool, tubular tool and hose ends are made of conductive material. Touching those parts, while the power cable of the vacuum cleaner is connected to the grounded power socket will dissipate the static charge, which can build up on the operators's body. For manoeuvrability and continues ESD protection connect a proper ESD wrist strap attachment to the metal clip on the cleaner body.
- 5 : The electrical motor of Convac 3000CQ has a thermal breaker, which will stop the motor if it overheats. The motor will restart automatically after 20 minutes. It is recommended to switch the cleaner off and let the motor cool down to its restarting temperature before switching again the vacuum cleaner on

### WARNING

Improper connection of the equipment-grounding can result in a risk of static electric shock. Check with electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with this appliance—if it will not fit the outlet, have the proper power outlet installed by a qualified electrician.

**AKB Longs B.V.**

Energieweg 50

2382 NN Zoeterwoude

Netherlands



## Technical Data

Motor: (UK/Europe) 220-240V 800W 50Hz  
(5 Amp Fuse)

Suction: Approx 1400 mmWG

Airflow: Approx 30 liters per second

Thermal Protection: Cut out 112 C

Automatic Reset: Approx 10-15 minutes

Dimensions: 457 mm x 190 mm x 241 mm

Weight: 5.5 Kg approx.

## Important Safety Instructions

**When using an electrical appliance, basic precautions should be followed, including the following:**

### **Warning : To reduce the risk of fire, electrical shock or injury**

- 1 : Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
- 2 : Do not use outdoors or on wet surfaces
- 3 : Do not allow to be used as a toy. Close attention is necessary when used near children.
- 4 : Use only as described in this manual. Use only attachments recommended by manufacturer.
- 5 : Do not use with damaged power cord or plug. If appliance is not working as it should, has been dropped, left outdoors or dropped into water, return it to a service centre.
- 6 : Do not pull or carry by power cord, use cord as a handle, close door on cord or pull cord around sharp edges or corners. Do not run appliance over the cord. Keep cord away from heated surfaces.
- 7 : Do not unplug by pulling on power cord. To unplug, grasp the plug not the cord.
- 8 : Do not handle plug or appliance with wet hands.
- 9 : Do not put any objects into openings. Do not use with any openings blocked, keep free of dust, lint, hair, or anything that may reduce airflow.
- 10 : Keep hair, loose clothing, fingers and all parts of your body away from openings.
- 11 : Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- 12 : Do not use without cartridge filter or second stage filter in place.
- 13 : Do not use to pick up any liquids. Never use to pick up flammable or combustible liquids or use in areas where they may be present.
- 14 : Use extra care when cleaning on stairs. Turn off all controls before unplugging.
- 15 : Connect to a properly grounded outlet.
- 16 : **Always disconnect power from the equipment you are going to service!** All attachments, hose, crevice tool, brush and tubular tool are conductive. Touching live parts with those tools can cause electric shock.

### **To Operate Convac 3000CQ**

- 1 : Release latch, open the lid and remove hose and cleaning tool required for the job from the tool holder.
- 2 : Remove the red end caps from the hose. **Do not throw them away !**
- 3 : Attach the cleaning tool to the hose.
- 4 : Unwind power cable, check that the power switch is OFF, and then plug the cord into the power socket.
- 5 : Close the lid and attach the hose to the vacuum inlet.
- 6 : Switch the power switch ON.

### **To Store Attachments for Transport**

- 1 : Disconnect cleaning tool from the hose and replace the red hose end caps to prevent spills
- 2 : Place, as the picture on the front page shows, the hose and accessory in the lid.
- 3 : Wind the power cord around the post, close the lid and latch it securely.

### **To Replace the Cartridge filter**

- 1 : Open the vacuum cleaner lid.
- 2 : Lift and remove the used cartridge filter from the cleaner
- 3 : Push a new cartridge filter into the cleaner body and close the lid.

**Used, filled with toner cartridge filters dispose in compliance with local regulations**